

**4+**

FOR AGES  
4 & ABOVE

**M**  
**MIRANA®**



# ***TRACER***



USB  
RECHARGEABLE



LONG LASTING  
BATTERY BACKUP



FULL  
FUNCTION



REMOTE  
CONTROLLED



POWERFUL  
BOOST



2.4  
GHZ



AERODYNAMIC  
DESIGN



ANTISKID  
TYRES



CHROME  
WHEELS



LUMINOUS  
HEAD LIGHT



BRIGHT  
TAIL LIGHT



1:20  
SCALE

## **WELCOME**

Please read this document and the safety instructions carefully  
before using the all-new remote controlled Tracer.  
Fully charge the battery before using it for the first time.

For detailed support information, visit our website

[www.miranatoys.com](http://www.miranatoys.com)

## 1. BUILT-IN BATTERY

The Remote Controlled Tracer comes with a rechargeable 1200 mAh battery. Don't attempt to modify, remove or replace the battery as it may damage it and cause overheating and injury. Do not cut, tear, puncture, compress or deform the Remote Controlled Tracer by disassembling it.

Follow the below instructions for charging its battery:

1. Turn the Remote Controlled Tracer upside down to check the charging port
2. Plug the USB charging cable provided in the box into the (5V-2A) DC input charging slot at the bottom of the Remote Controlled Tracer
3. Red LED will glow up while charging
4. Green LED will glow up when the Remote Controlled Tracer is fully charged
5. Remove the adapter when the Green LED glows up


## 2. REMOTE CONTROL

### BATTERY INSTALLATION


For the Remote Controlled Tracer, you need to install 2 batteries of 1.5V "AA" type.

Follow the below instructions for installation:

1. Invert the remote control console and unscrew the battery compartment
2. Install new batteries (+/-) inside the compartment carefully
3. Place the battery compartment lid securely and your remote control console is ready to use



Use 2 x 1.5v "AA" Battery



1200 mAh Rechargeable  
Li-Ion Battery (Included)


C Type USB Charging Port

### 3. PLAYING INSTRUCTIONS

1. Turn on the Remote Controlled Tracer with the switch given at its bottom and place it on a flat surface
2. Your remote control console is ready to use once the battery compartment lid is placed securely
3. Switch on the power button of the remote control and a red indicator light will glow up on top
4. Hold the remote control near your Remote Controlled Tracer to pair
5. Use the remote control console to drive the Remote Controlled Tracer
6. For directional control, use the left round button on the controller for moving the vehicle forward and backwards. Use the right round button for turning left or right
7. For an extra burst of speed, you can use the button on the left side situated at the front of the controller to activate the Boost function
8. The button on the right side situated at the front of the controller can be used for switching on the headlights of the Remote Controlled Tracer

### 4. SAFETY PRECAUTIONS

The Remote Controlled Tracer should be used by children aged 4 years or above. While using it for the first time, this toy car should be safely set-up under adult supervision. Do not try to modify any part of this toy car, which may negate your authority to use it. Rechargeable batteries of this Remote Controlled Tracer should be charged under adult supervision only. While charging the toy car, do not touch the electric outlet and the charging port with bare / wet hands to avoid electric shock like other electric products. Do not use damaged electric outlets for charging batteries. Do not attempt to charge non-rechargeable / replaceable batteries of the controller. Parental guidance is recommended when installing or replacing the batteries in the remote control console. Adults should examine the USB cable, plug, enclosure or other parts of the Remote Controlled Tracer regularly. Strictly adhere to this instruction manual while operating the toy car.



## ATTRACTIVE STICKERS

Spruce up your toy with the stunning stickers provided in the box. Paste them yourself and see your Remote Controlled Tracer transform into an attractive looking toy car.

All stickers are true to size and are kiss cut / die-cut with high precision. Colorful and pretty designs, these stickers are easy to apply.

## CARE AND MAINTENANCE

Always remove batteries from the remote control console when they have drained out completely or are not in use for a longer period of time. Keep it away from direct sunlight, high humidity, high temperature or excess heat. Ensure that the tires are clean for optimized grip. Gently wipe the tires with a damp cloth whenever they become dirty. Do not immerse the Remote Controlled Tracer or any part of it in water to clean it. This can damage its electronic components. Before using the toy car, please ensure that it is not damaged and safe to use.

## DISPOSAL INFORMATION

Never dispose of the Remote Controlled Tracer and / or its battery along with the household waste. If / When you decide to dispose of this toy car and / or its battery, discard it in e-waste container that are in accordance with the local environmental laws, guidelines and battery recycling procedures.




Manufactured by:

**MIRANA INNOVATIONS PRIVATE LIMITED**

201, Plot No. T33, T Block, MIDC Road, Bhosari, Pune, MH, India - 411 026.

For Feedback and complaints, contact us at [info@miranatoys.com](mailto:info@miranatoys.com)



[www.miranatoys.com](http://www.miranatoys.com)